

VENT & ADAPTER 90500

Mounting instructions

Fixings:

Screw M4/Ø4

Rivet Ø4

Installing

Select the mounting adapter according to the mounting method.

- Drill installing hole for the adapter.
 - Attach the adapter with screws.
 - Attach the vent to the adapter, grilles down and horizontally. the vent locks with clamping claws squeezing in place.
- Installing hole 76-79 mm

